


Roofing Coil Nailer—Traditional Side Load



Roofing Coil Nailer—Traditional Side Load

Item	Part No.	Description	Item	Part No.	Description	Item	Part No.	Description
1	820648	Hex. Socket HD. Bolt M5x25	37	841715	Pushing Lever	72	841846	Shaft Ring
2	841833	Top Cover	38	841678	Washer	73	841847	Nail Guide Shaft
3	840899	Warning Label (A)	39	841840	Grip Rubber	74	841848	Adjuster
4	841834	Exhaust Cover (B)	40	841841	Gasket (D)	75	841849	Adjuster Spring
5	841684	Protector	41	841842	Cap	76	841850	Bolt
6	841683	Body Guard	42	841843	Hex Socket HD Bolt M5x16 (10pcs)	77	841851	Nail Guide
7	841688	Gasket (F)	43	920320	Dust Cap	78	841728	Lock Shaft
8	841835	Gasket (G)	44	940620	Air inlet plug 3/8"	79	841729	Guide Lock
9	841685	Exhaust Valve	45	831025	Roll Pin D3x30(10pcs.)	80	841730	Roll Pin D3x10(10pcs.)
10	841836	Head Cap	46	841702	Plunger Spring	81	810818	Spring
11	841689	Piston O-ring	47	830235	Plunger O-ring	82	841733	Main Stopper Spring
12	841690	Piston(H)	48	841703	Plunger (A)	83	830641	Hex. Socket HD. Bolt M4x6 (10pcs.)
13	841691	O-ring (S-65)	49	841704	Valve Bushing	84	841852	Roll Pin D3x10(10pcs.)
14	841692	Cylinder O-ring	50	830305	O-ring(S-12)	85	841731	Main Nail Stopper
15	841693	Cylinder Plate	51	820313	Valve Packing	86	841732	Nail Stopper
16	841694	Cylinder	52	841707	Urethane Ball (c) D7.14	87	920556	Sub Stopper Spring
17	841695	Cylinder Ring	53	810540	Valve Plate	88	841734	Nail Guide Cover
18	841696	Cylinder Spring	54	820351	Trigger Valve Bushing	89	841853	Magazine Cover
19	841697	Cylinder O-ring (A)	55	820364	Trigger Plunger	90	841854	Holder Cap
20	841698	Cylinder Guide	56	830235	Trigger Plunger O-ring	91	841855	Machine screw M4x50 (10pcs.)
21	841699	Cylinder O-ring (B)	57	810402	Trigger	92	841856	Spring Washer M4(10pcs.)
22	841837	Warning Label	58	841705	Plunger (B)	93	841857	Washer M4(10pcs.)
23	841838	Body Ass'y	59	841706	Valve Rubber Cover	94	841858	Holder Shaft
25	841710	Cylinder O-ring	60	841737	O-ring(P-9)	95	841859	U-Nut M5
26	841700	Piston Bumper	61	841739	Feed Piston O-ring(I.D.14)	96	841860	Sleeve
27	841701	Bumper Sheet	62	841738	Feed Piston	97	841861	Ratchet Spring
28	841711	Gasket (A)	63	841740	Feed Piston O-ring(I.D.11)	98	841862	Nail Holder
29	920365	Hex Socket HD Bolt M5x8 (10pcs)	64	841837	Gasket (E)	99	841863	Magazine
30	841721	Guard	65	841838	Feed Piston Cover	100	841864	Pin
31	841871	Nose	66	841743	Magazine Bushing	101	841865	Nylon Nut M4
32	841713	Nose Guard	67	920170	Hex. Socket HD Bolt M5x10(10pcs.)	102	841866	Magazine Guard
33	841714	Nylock Hex. Socket HD Bolt M5x16	68	841720	Feeder Spring	103	841867	Plate Nut
34	841716	Spring	69	841845	Feeder (A)	104	841868	Guide Base
35	820688	Safety Bolt	70	841719	Feeder Shaft	105	841869	Hex Socket HD Bolt M5x14 (10pcs.)
36	841717	Nut M5(10pcs.)	71	820051	Feeder Shaft Ring	106	841870	Shingle Guide